

## OPERATING YOUR **3 LEVER MECHANISM** WITH SEAT SLIDE & TILT TENSION CONTROL



**FRONT**

### **A) SEAT HEIGHT CONTROL**

Lift and hold the lever upwards to set the seat to the correct height. Release when desired height is reached.

Note: When raising the height, remove your body weight from the seat.

### **B) BACK ANGLE**

Adjusts the angle of the back. Lift this lever to adjust, and lower when desired angle is achieved.

### **C) SEAT TILT**

Adjusts the angle of the seat. Lift this lever to adjust, and lower when desired angle is achieved.

### **D) TILT TENSION CONTROL**

This feature enables to control the fluid motion of the Seat Tilt. This adjustment correlates as per the weight of the person sitting on it. Rotate clockwise to increase the tension and counter-clockwise to loosen the tension.

### **E) SEAT SLIDE CONTROL**

To use the seat slide function, pull the lever up, and hold it firmly. Then use your hips and legs to move the seat forward or rearwards until the depth of the seat is at the desired position; then release lever and the seat will stay locked in that position.

***Please note: The Seat Slide is an optional feature that can only be purchased as an upgrade. Your chair may not have this function.***