

OPERATING YOUR 3 LEVER MECHANISM & SEAT SLIDE



FRONT

A) SEAT HEIGHT CONTROL

Lift and hold the lever upwards to set the seat to the correct height. Release when desired height is reached.

Note: When raising the height, remove your body weight from the seat.

B) SEAT TILT

Adjusts the angle of the seat. Whilst seated, lift and hold this lever upwards while using your hips and thighs to angle the seat in your desired position. Release lever to set the angle.

C) BACK ANGLE

Adjusts the angle of the back. Whilst seated, lift and hold this lever upwards while using your back and core to angle the back in your desired position. Release lever to set the angle.

D) SEAT SLIDE CONTROL

To use the seat slide function, pull the lever up, and hold it firmly. Then use your hips and legs to move the seat forward or rearwards until the depth of the seat is at the desired position; then release lever and the seat will stay locked in that position.

Please note: The Seat Slide is an optional feature that can only be purchased as an upgrade. Your chair may not have this function.

OPTIONAL CHAIR FEATURE: THE LUMBAR AIR PUMP

- ① Inflate bladder to increase lumbar support.
- ② Press and hold button to release lumbar support.

