


## OPERATING YOUR 3 LEVER MECHANISM WITH SEAT SLIDE & TILT TENSION CONTROL



FRONT

### A) SEAT HEIGHT CONTROL

Lift and hold the lever upwards to set the seat to the correct height. Release when desired height is reached.

**Note:** When raising the height, remove your body weight from the seat.

### B) BACK ANGLE

Adjusts the angle of the back. Whilst seated, lift and hold this lever upwards while using your back and core to angle the back in your desired position. Release lever to set the angle.

### C) SEAT TILT

Adjusts the angle of the seat. Whilst seated, lift and hold this lever upwards while using your hips and thighs to angle the seat in your desired position. Release lever to set the angle.

### D) TILT TENSION CONTROL

This feature enables to control the fluid motion of the Seat Tilt. This adjustment correlates as per the weight of the person sitting on it. Rotate clockwise to increase the tension and counter-clockwise to loosen the tension.

### E) SEAT SLIDE CONTROL

To use the seat slide function, pull the lever up, and hold it firmly. Then use your hips and legs to move the seat forward or rearwards until the depth of the seat is at the desired position; then release lever and the seat will stay locked in that position.

**Please note:** The Seat Slide is an optional feature that can only be purchased as an upgrade. Your chair may not have this function.

