

OPERATING YOUR HEAVY DUTY 3 LEVER MECHANISM



A) SEAT TILT

Adjusts the angle of the seat. Whilst seated, lift and hold this lever upwards while using your hips and thighs to angle the seat in your desired position. Release lever to set the angle.

Place both hands on the bottom (either side) of the backrest and lift upwards to raise or pull downwards to lower.

Once desired height is reached, rotate the dial forwards to lock into position.

B) SEAT HEIGHT CONTROL

Lift and hold the lever upwards to set the seat to the correct height. Release when desired height is reached.

Note: When raising the height, remove your body weight from the seat.

E) SEAT TILT TENSION

This feature enables to control the fluid motion of the seat tilt. Rotate clockwise to increase the tension and counter-clockwise to loosen the tension.

C) BACK ANGLE

Adjusts the angle of the back. Whilst seated, lift and hold this lever upwards while using your back and core to angle the back in your desired position. Release and lower lever to lock into place.

D) BACK HEIGHT ADJUSTMENT

To correctly position the back height, rotate the dial backwards until loosened.

OPTIONAL CHAIR FEATURE: THE LUMBAR AIR PUMP

- ① Inflate bladder to increase lumbar support.
- ② Press and hold button to release lumbar support.

